

Operating instructions for the Dermalux Multimedia Cam 2008

Operation of the Dermalux Checkbox with the Dermalux Multimedia Cam 2008

Connect the colour camera module (1) to the Dermalux Checkbox Multimedia. To do this, carefully insert the plug on the short cable of the camera module into the socket located at the TOP on the right-hand side of the Checkbox housing. Align the plug precisely before inserting it, so that it can be inserted without pressure and does not damage the pins in the socket. Remove the small protective cap from the camera head before putting into operation. Focus manually as desired using the lens. In the case of use with a beamer, first make small corrections as necessary only after the beamer has been focussed.

Connection of the Dermalux Multimedia Cam 2008 to TVs and video recorders

Connect the cinch cable (3) likewise to the Dermalux Checkbox Multimedia. The socket for the cinch plug is located at the BOTTOM on the right-hand side of the Checkbox housing, in the rear corner below the carrying handle curve. The cinch cable is then connected to the TV, monitor or video recorder. For display devices with scart sockets, first connect the scart adaptor plug (2) to the cinch cable (3) and then connect to the scart socket on the video recorder/TV. Select the video/AV setting on the TV.

Connection of the Dermalux Multimedia Cam 2008 to a beamer

Connect the cinch cable (3) to the Dermalux Checkbox Multimedia as described above and connect to the beamer via the video input.

For beamers with scart sockets, first connect the scart adaptor plug (2) to the cinch cable (3) and then connect to the scart socket on the beamer.

Repair service

Our repair service at the Ott company in Koblenz can be contacted by telephone under +49 (0) 261/982422-3 or by fax under +49 (0)261/982422-5. Please contact Mr Ott junior.

Get additional information and place your orders here:

KBD GmbH
Kaiserstrasse 35
D- 69469 Weinheim
Phone: 0049-6201-5900-65
Fax: 0049-6201/5900-66
E-mail: info@dermalux.de
www.dermalux.de
www.dermalux-hygiene.com